


# Polycarbonate greenhouse

Premium Tomato polycarbonate 210x204



Scan to see the assembly video

## Assembly manual

We are grateful that you have decided to purchase PTF Polska Greenhouse. We believe that it will help you in growing your flowers and vegetables and that you will be satisfied a lot. We did our best so that the design and modern technical solutions are helpful in the cultivation and so that the assembly is simple and easy.



max 60 km/h

### WARNING!

In strong windy weather, it is necessary to close all the door and window openings and secure them so that the wind cannot open them. During gusty winds, thunderstorms, hailstorms, rains and other adverse atmospheric conditions, it is forbidden to stay in the greenhouse. During high insolation, high temperatures may be reached; therefore, all the works in the hotbeds must be carried out early in the morning or in the evening with the doors opened on both sides of the greenhouse. It is forbidden to close oneself inside the structure.

**The greenhouse is not a toy; therefore, children may stay there only when attended by adults.**



max 30 kg/m<sup>2</sup>

### CAUTION!

In winter, it is necessary to pay particular attention to the structure so that wet and heavy snow is not deposited on it – it may damage the greenhouse. If it is not possible to control the level of snow, it is required to dismantle the cover of the side walls, front and roof for the winter period. The structure may be left for the winter period.

**It is forbidden to enter the greenhouse from which snow is not removed – snow deposits may deform the structure and lead to the collapse of the roof or door, and prevent exiting the hotbed. Greenhouse roof must be densedown regularly.** If the greenhouse is not used in winter, it is necessary to secure the door in order to prevent the access of unauthorised personnel and children.

### Safe use rules:

1. The greenhouse is dedicated only to plant growing.
2. Mount the greenhouse to the foundation with the indicated mounting holders included in the set.
3. Mount the structure in the place not exposed to strong wind blows; avoid slopes and open spaces. Greenhouse wind resistance: 60 km/h.
4. Do not assemble the greenhouse in strong winds and in other adverse weather conditions.
5. Keep children away from the assembly site because the set includes small elements and foil bags which may lead to choking or suffocating.
6. Check the stability of the greenhouse regularly, especially after storm winds or heavy snowfalls. If you notice any damage, replace a damaged element or disassemble the structure.
7. Use assembly tools specified in the manual and wear protective gloves and glasses during the greenhouse assembly and maintenance.
8. Avoid using mowers and mechanical scythes near the structure.
9. Do not keep hot objects, especially hot barbecue equipment, etc. in the greenhouse.
10. Remove snow, branches and leaves regularly from the greenhouse roof in order to prevent its damage, what in consequence may be dangerous to greenhouse users.  
Max. greenhouse roof load: 30 kg/m<sup>2</sup>.
11. Do not climb the structure roof.
12. Do not leave children unattended in the greenhouse because the door may close and prevent children from exiting the structure.
13. Do not use open flame in or near the structure.
14. Do not load roof panels additionally (with the exception of tied-up plants).
15. The greenhouse cannot be used in the public space.

### FOLLOW THE OHS RULES



Wear protective gloves during the assembly



Wear protective glasses during the assembly



Provide help from the assistant during the assembly



The temperature in the greenhouse is high



Perform assembly on days which are not windy




It is prohibited to have the structure assembled by drunk and intoxicated personnel

# Ground


THE STRUCTURE MUST BE FASTENED TO THE GROUND PERMANENTLY. OTHERWISE, IT WILL BE CAUGHT BY THE WIND AND IT MAY CAUSE INJURIES!

GROUND TYPE:

## Concrete blocks




standard concrete  
block 24x12x38  
weight approx. 22-25kg



! Pay attention so  
that the greenhouse  
mounting is not  
located at the blocks  
connection.

The blocks should be dug completely into the ground and laid on a cement mortar (connected with each other) to form a dense solid with the length and width provided in the drawing. Fill the joints with the cement mortar.

## Concrete foundation



### Location

Do not assemble the greenhouse on open spaces, on slopes and in locations particularly exposed to wind blows – this will extend the service life of the hotbed significantly and make the use of PTF POLSKA polycarbonate greenhouse satisfactory for a longer period of time.

**The correct mounting of the greenhouse to the ground will protect the product against being caught by the wind.**












PTF Polska is not held responsible for:

- the incorrect use of the greenhouse and destruction as a result of extreme weather conditions (hailstorm, storm winds, snow). The ground must be even and levelled.
- damage due to the greenhouse being caught by the wind (it applies to product damage and damage caused by the greenhouse).

**The user is responsible for the reliable assembly of the product and its secure fastening to the ground.**


# List of elements

PVC



CHECK WHETHER THE PACKAGING INCLUDES ALL THE ELEMENTS.  
We recommend elements sorting before their assembly. This will facilitate assembly works.

# List of elements





CHECK WHETHER THE PACKAGING INCLUDES ALL THE ELEMENTS.  
We recommend elements sorting before their assembly. This will facilitate assembly works.




# Tools and components not included



The DIY assembly greenhouse lacks some tools.  
Provide necessary tools before starting work.







In order to fasten the greenhouse securely to the  
concrete ground prepared earlier, use concrete  
anchors and proper tools.




# 1

Side wall height = 142cm  
Peak height = 191cm  
Door clearance = 70x166cm



Hammer in the profiles with a rubber hammer (not a steel one)




elements

**x10** - 640mm  
P-01

PVC





**x4**  
Z-01




**x4**  
Z-05

2





elements





3





elements

PVC




x8 - 1360mm  
P-09

4




elements

PVC




x4 - 1660mm  
P-02


5





1025mm from the ground to  
the profile centre




elements



6





elements



**x4**  
Z-08


7



elements





x2  
Z-06




x2  
Z-07

8





elements





x4  
Z-11



9



elements



10





elements

PVC


x4 - 1115mm  
P-04





11




elements



12



elements





x2  
Z-10

PVC




x4 - 1115mm  
P-04


13




joined elements




14



A



B










elements

PVC



**x3** - 640mm  
P-01

15



x4


elements




x1  
SPANNER 13










x8  
CONCRETE  
ANCHOR M8



x2  
5mm DRILL  
and CONCRETE DRILL




x8  
MC




x4


## elements




x1  
SPANNER 13





x4  
CONCRETE  
ANCHOR M8




x2  
5mm DRILL  
and CONCRETE DRILL





x4  
MC






# elements







# 19



## CAUTION

UV PROTECTIVE COAT ON THE SIDE MARKED WITH AN OVERPRINTED TAPE. MOUNT WITH THIS SIDE OUTSIDE!

elements




**x2**  
PL-3



**x2**  
PL-2



**x2**  
PL-2





**x3**  
PW-1



Read the description on the sticker placed on the foil


20







All the boards must be coated with UV tape




Read the description on the sticker placed on the foil




21



elements



**x1**  
8 MAGNETIC BIT



**x70**  
W2



**x2**  
PL-3






**x2**  
PL-2




**x2**  
PL-2

22




elements



x1  
8 MAGNETIC BIT






x24  
W2




x2  
PW-1

23




elements



**x1**  
8 MAGNETIC BIT



**x26**  
W2





**x1**  
PW-1


24



Drilling the board.





elements




**x1**  
5mm DRILL

25




elements


x1  
SPANNER 8




x1  
8 MAGNETIC BIT




x48  
SM-1



26





elements





27



**CAUTION**

UV PROTECTIVE COAT ON THE SIDE  
MARKED WITH AN OVERPRINTED TAPE.  
MOUNT WITH THIS SIDE OUTSIDE!

elements




**x2**  
PL-1



Read the description  
on the sticker placed  
on the foil

28



Read the description  
on the sticker placed  
on the foil

elements




x2  
PL-1





x1  
UV ADHESIVE  
TAPE

# 29




**x2**




Place the screws evenly

elements




**x1**  
8 MAGNETIC BIT



**x48**  
W2




**x2**  
PL-1



**x2**



# 30



Hinge assembly






Place the screws evenly




Mount the hinge on the polycarbonate board.  
Left and right hand side assembly is possible.

elements




x8  
HINGE


# 31




Mount the hinge on the polycarbonate board.




IT IS POSSIBLE TO DIVIDE THE DOOR IN THE BOARD BENDING PLACE. FOR THIS PURPOSE, AFTER MOUNTING THE DOOR, THE BOARD MUST BE CUT THROUGH WITH A KNIFE.



elements



**x1**  
SCREWDRIVER








**x16**  
W3




**x2**

32



elements





Manufacturer

**Eurosat sp. z o. o.**

ul. Nowozachęty 14

41-407 Imielin, POLAND



+48 32 223 11 86

+48 503 085 265



biuro@tunelefoliowe.eu